

CARBURATION

NÉCESSAIRES POUR CARBURATEURS / CARBURETOR KITS

FABRIQUÉS AU JAPON / MADE IN JAPAN



| Modèle / Model | Année / Year | # Pièces / Part # |
|--------------------|--------------|-------------------|
| POLARIS | | |
| Trail Blazer | 1990-95 | 016-401 |
| Trail Boss 2x4/4x4 | 1989-93 | 016-401 |
| Trail Boss | 1989-99 | 016-401 |
| 2x4, 4x4 300 | 1994-95 | 016-402 |
| Xpress 300 | 1996-99 | 016-402 |
| Xplorer 300 | 1996-99 | 016-402 |
| Magnum 330 2x4 | 2003-05 | 016-409 |
| Magnum 330 4x4 | 2003-05 | 016-409 |
| Trail Boss 330 | 2003-05 | 016-409 |
| Trail Boss 350 | 1992-93 | 016-403 |
| Sportsman 4x4 | 1993 | 016-403 |
| Sportsman 4x4 | 1994-95 | 016-404 |
| 2x4/4x4 400L | 1994 | 016-404 |
| Sport 400 | 1994-95 | 016-404 |
| Xplorer 400 4x4 | 1995 | 016-404 |
| Trail Blazer | 1996-00 | 016-405 |
| Xplorer 4x4 | 2000 | 016-405 |
| Scrambler 400 4x4 | 1997-00 | 016-406 |
| Scrambler 400 2x4 | 2000-01 | 016-406 |
| Xplorer 400 | 1997-02 | 016-407 |
| Scrambler 500 2x4 | 2001-02 | 016-408 |
| Scrambler 500 4x4 | 1998-02 | 016-408 |
| Scrambler 500 4x4 | 2003-05 | 016-410 |
| Sportsman 500 | 2002 | 016-408 |
| Sportsman 500 | 2003 | 016-410 |
| SUZUKI | | |
| LT 80 | 1987-98 | 016-210 |
| ALT/LT 125 | 1983-87 | 016-201 |
| LTF 160 | 1991-98 | 016-208 |
| LT 230 GE | 1985-86 | 016-204 |
| LT 230 | 1986-87 | 016-204 |
| LT 230 E | 1989-93 | 016-205 |
| LT 230S | 1985-88 | 016-202 |
| LT 250R | 1985-86 | 016-203 |
| LT 4 WD | 1987-89 | 016-206 |
| LT 4 WD | 1990-96 | 016-207 |

| Modèle / Model | Année / Year | # Pièces / Part # |
|----------------|--------------|-------------------|
| SUZUKI | | |
| LTF 250 | 1988-89 | 016-206 |
| LTF 250 | 1990-96 | 016-207 |
| LTF 250 | 1997-99 | 016-211 |
| LTF 250 | 2000-01 | 016-214 |
| LTF 250 | 2003-07 | 016-215 |
| LTF 250 F | 1999 | 016-211 |
| LTF 250 F | 2000-02 | 016-214 |
| LTF 250 4WD | 1997-98 | 016-211 |
| LT 4 WDX | 1991-98 | 016-209 |
| LTA 400 F | 2003-06 | 016-213 |
| LTF 500 F | 1998-02 | 016-212 |
| LTF 500 | 2003-06 | 016-216 |
| YAMAHA | | |
| YFM 80 | 1992-94 | 016-309 |
| YFA-1 | 1989-04 | 016-319 |
| YFM125 | 2004-06 | 016-319 |
| YFM 200 | 1986-89 | 016-310 |
| YFS 200 | 1988-95 | 016-301 |
| YFB 250/U | 1992-98 | 016-306 |
| YFB 250 FW | 1994-98 | 016-306 |
| YFM 250 | 1989-91 | 016-302 |
| YFM 250 | 1999-04 | 016-316 |
| YFM 350 ER | 1989-93 | 016-304 |
| YFM 350 FW | 1989-93 | 016-304 |
| YFM 400 FW | 1993-95 | 016-304 |
| YFM 350 X | 1988-2002 | 016-307 |
| YFZ 350 | 1988-2002 | 016-308 |
| Big Bear 400 | 2000-04 | 016-312 |
| Kodiak 400 | 1996-98 | 016-311 |
| Kodiak 400 | 2000-04 | 016-313 |
| YFM 450 | 2003-04 | 016-317 |
| YFZ 450 | 2004-06 | 016-320 |
| YFM 600 | 1998-2001 | 016-314 |
| YFM 660 | 2002-05 | 016-318 |
| YFM 660 R | 2001-04 | 016-315* |

*Pour 2 Carburateurs. / For 2 Carburetor

CARBURATION

ENSEMBLES POINTEAU & SIÈGE – NEEDLE & SEAT SETS



| Modèle / Model | Année / Year | # Pièces / Part # |
|-----------------------------|--------------|-------------------|
| POLARIS | | |
| 250 2x4/4x4/6x6 | 1993 | NS010 |
| 300 2x4/4x4 | 1994-95 | NS010 |
| 300 6x6 | 1994 | NS010 |
| 350L 2x4/4x4/6x6 | 1993 | NS010 |
| 400L 2x4 | 1994-95 | NS015 |
| 400L 4x4 | 1994 | NS015 |
| 400L 6x6 | 1994 / 1996 | NS015 |
| Big Boss | 1989 | NS010 |
| Big Boss 4x6 | 1989-92 | NS010 |
| Big Boss 6x6 | 1991-92 | NS010 |
| Big Boss 6x6 400L | 1995 / 1997 | NS015 |
| Cyclone | 1987 | NS010 |
| Scrambler | 1985-86 | NS010 |
| Scrambler 4x4 | 1995 | NS015 |
| Scrambler | 1996 | NS015 |
| Scrambler 400L | 1997 | NS015 |
| Scrambler 400 | 1998-2000 | NS015 |
| Scrambler 500 | 1998-2000 | NS020 |
| Scrambler 500 2x4/4x4 | 2001 | NS020 |
| Scrambler 2x4 | 2000-01 | NS015 |
| Sport 400L | 1994-98 | NS015 |
| Sport 400L | 1996-97 | NS010 |
| Sport 400 | 1999 | NS015 |
| Sportsman 4x4 | 1993 | NS010 |
| Sportsman 4x4 | 1994-96 | NS015 |
| Sportsman 400L | 1997 | NS015 |
| Sportsman 500 DUSE HO | 2001 | NS020 |
| Sportsman 500 HO | 2001 | NS020 |
| Sportsman 500 RSE HO | 2001 | NS020 |
| Sportsman 500 (All options) | 2002 | NS020 |
| Trail Blazer | 1990-01 | NS010 |
| Trail Blazer ES | 1996 | NS015 |
| Trail Blazer | 1997 | NS015 |
| Trail Boss | 1985-99 | NS010 |
| Trail Boss 250 | 1990-92 | NS010 |
| Trail Boss 250 | 1995 | NS010 |
| Trail Boss 2x4 | 1988-92 | NS010 |
| Trail Boss 350L 2x4/4x4 | 1990-92 | NS010 |
| Trail Boss 4x4 | 1987-92 | NS010 |

CARBURATION

ENSEMBLES POINTEAU & SIÈGE – NEEDLE & SEAT SETS

| Modèle / Model | Année / Year | # Pièces / Part # |
|-----------------------|---------------------|--------------------------|
| POLARIS | | |
| W948040 | 1994 | NS015 |
| Worker 500 | 2001 | |
| Xplorer | 1995 | NS015 |
| Xplorer 300 | 1996-99 | NS010 |
| Xplorer 400L | 1996-98 | NS015 |
| Xplorer 400 | 1999-2001 | NS015 |
| Xplorer | 2000-01 | NS010 |
| Xpress 300 | 1996-97 | NS015 |
| Xpress 300 | 1996-99 | NS010 |
| Xpress 400 | 1996-97 | NS010 |
| Xpress 400 | 1996-97 | NS015 |