

# SYSTÈME ÉLECTRIQUE - 1 - ELECTRICAL SYSTEM

## RUPTEURS - CONTACT SETS

**CS100**

**Bosch 1217013012, 1217013016, 1217013102  
Hirth - Kohler (MAG) - Rockwell  
Rotax - Sachs - Solo**



(01-136)

**CS101**

**Bosch 1217013015, 1217013103, 1217013006 1.2560  
Gutbrod - Hirth - Kohler (MAG)  
Rockwell, Rotax, Sachs, Solo**



(01-135)

**CS103**

**Bosch 1217013020 1.2583  
Rotax 420.983.349**



(01-136-04)

**CS104**

**Bosch 1217013021 1.2568  
Rotax - Kohler**



(01-136-03)

**CS105**

**Bosch 2207013002 1.2564  
Gutbrod - Rotax**



(01-135-01)

**CS106**

**Mobylette**



**CS107**

**Peugeot**



**CS109**

**Yamaha 806-81321-20-00  
Sno Jet (810365)**



(01-137)

# SYSTÈME ÉLECTRIQUE - 1 - ELECTRICAL SYSTEM

## RUPTEURS - CONTACT SETS

**CS110**

**Arctic Cat** 3000-077  
**CCW** 25000459 - 25000451



(01-139-04)

**CS111**

**Arctic Cat** 3000-182



(01-139)

**CS112**

**Arctic Cat** 3000-947  
**Kawasaki** 21008-507



(01-138-01, 01-139-07)

**CS113**

**Polaris** 3081257, 3080272 utiliser / use 3082173



(01-138-04)

**CS114**

**Rupp** 17045



(01-139-02)

**CS116**

**CCW** 18000 - 18510



(01-139-03)

**CS118**

**Bosch** 2207110005  
**Polaris** 325241



# SYSTÈME ÉLECTRIQUE - 1 - ELECTRICAL SYSTEM

## RUPTEURS - CONTACT SETS

**CS119**

**B.S.E. - Moto-Ski** 540.8011.69



(01-139-09)

**CS120**

**Arctic Cat** 3002-806  
**Spirit Engine**



(01-139-08)